

AIR/WATER TIRE GAUGE INSTRUCTIONS

TIRE GAUGE

You can improve your gas mileage by around 3.3% by keeping your tires inflated to the proper pressure. Under-inflated tires can lower gas mileage by 0.4% for every 1 PSI drop in pressure of all four tires. Properly inflated tires are safer and last longer.

Proper Use:

- Check pressure before driving
- Make sure valve is free of dirt and debris
- Press gauge firmly onto valve stem and verify pressure reading
- If necessary, add additional air

NOTE: Do NOT over-inflate.

SPECIFICATIONS: PRESSURE RANGE 5–50 PSI

MEDIDOR DE AIRE

Usted puede mejorar el rendimiento del combustible en alrededor del 3.3% al mantener sus llantas infladas a la presión indicada. Las llantas mal infladas pueden reducir el rendimiento de la gasolina en un 0.4% por cada disminución de 1 PSI en las cuatro llantas. Las llantas infladas correctamente son más seguras y duran más.

Uso Apropriado:

- Revise la presión antes de conducir
- Asegúrese de que la válvula no tenga suciedad ni residuos
- Presione el medidor firmemente sobre el vástago de la válvula y verifique la lectura de la presión
- Si es necesario, agregue más aire

NOTA: NO sobre-infle.

ESPECIFICACIONES: RANGO DE PRESIÓN: 5–50 PSI