

SKABS INSTRUCTIONS

6 PRE-GLUED PATCHES & SCUFFER

To apply pre-glued patches:

- Roughen puncture area with enclosed metal scuffer and wipe clean.
- Peel off the patch backing while not touching or allowing the adhesive to become contaminated.
- Apply patch over the puncture and press firmly.
- Insert inner tube into tire casing and re-inflate.

6 PARCHES CON PEGAMENTO Y RASPADOR

Para aplicar parches que ya contienen pegamento:

- Raspe el área de la punción con el raspador metálico incluido y límpiela.
- Desprenda el recubrimiento del parche sin tocar ni permitir que el adhesivo se contamine.
- Aplique el parche sobre la punción y presiónelo con firmeza.
- Inserte la cámara en la llanta y vuelva a inflarla.