

# ***DIGITAL TECH GAUGE INSTRUCTIONS***

## ***DIGITAL TECH GAUGE***

You can improve your gas mileage by around 3.3% by keeping your tires inflated to the proper pressure.

### **Proper Use**

1. Push button to turn on gauge, when LCD reads “0.0” it is ready to measure PSI.
2. Make sure valve is free of dirt and debris.
3. Press gauge firmly onto valve stem and read pressure on display.

**NOTE:** Gauge will turn off automatically. Do NOT over-inflate.

**BLEEDER PIN:** Press bleeder pin into valve to engage core and release tire pressure.

## ***INDICADOR DIGITAL TECH***

Usted puede mejorar en 3.3 % el kilometraje de la gasolina si mantiene las llantas a la presión adecuada.

### **Uso adecuado:**

1. Oprima el botón para encender el indicador, cuando la pantalla LCD indique “0.0”, está listo para medir la presión de la llanta en libras por pulgada cuadrada (psi).
2. Asegúrese que la válvula esté libre de tierra y suciedad.
3. Empuje el indicador firmemente contra el vástago de la válvula y lea la presión que aparece en la pantalla.

**IMPORTANTE:** El indicador se apaga automáticamente. Las llantas NO se deben inflar demasiado.

**PERNO PARA DESINFLAR:** Oprima el perno para desinflar hacia dentro de la válvula para acoplar el vástago y la liberar presión de la llanta.